

IToolCo

User's Guide



AXLES

100 MECO LANE | OAK RIDGE, TN 37830 | 865.483.2040 | ITOOLCO.COM
© 2017 PROPERTY OF ITOOLCO



BEFORE OPERATION OF THIS TOOL, READ AND UNDERSTAND ALL OF THE INSTRUCTIONS AND SAFETY INFORMATION IN THIS MANUAL



Contents

SAFETY FIRST 3

SAFETY ALERT SYMBOLS 3

IMPORTANT SAFETY INFORMATION FOR ITOOLCO REAL JACKS 4

DESCRIPTION AND OPERATION 5

SET UP AND OPERATION 6

LIMITED WARRANTY: ITOOLCO REAL JACKS 6

SAFETY FIRST

Safety is essential in the use and maintenance of this tool. This instruction manual and any markings on the tool provide information for avoiding hazards and unsafe practices related to the use of this tool. Observe all of the safety information provided.

SAFETY ALERT SYMBOLS

This symbol is used to call your attention to hazards or unsafe practices that could result in injury or property damage. The three signal words, defined below, indicate the severity of the hazard. The message after the signal word provides the information for preventing or avoiding the hazard.



DANGER

Immediate hazards that, if not avoided, **WILL** result in severe injury or death.



WARNING

Hazards that, if not avoided, **COULD** result in severe injury or death.



CAUTION

Hazards or unsafe practices that, if not avoided, **MAY** result in injury or property damage.

IMPORTANT SAFETY INFORMATION FOR ITOOLCO AXLES



WARNING

Read and understand all instructions and safety information in this manual before operating or servicing this tool.
FAILURE TO OBSERVE THESE WARNINGS CAN RESULT IN SEVERE INJURY OR DEATH



WARNING – PERSONAL SAFETY HAZARDS

Only qualified persons should use iTOOLCO Axles.
Wear eye protection and hard hat when using this tool.
Do not use this tool while tired or under the influence of drugs, alcohol, or medication.
Keep body parts and loose clothing away from moving parts.
Always follow operating procedures.
Make sure bystanders are clear of the work area when loading, unloading or dispensing cable onto iTOOLCO Axles.
Do not use with damaged reels. Damaged reels may not roll freely and may be pulled off the axle.
FAILURE TO OBSERVE THESE WARNINGS CAN RESULT IN SEVERE INJURY OR DEATH.



WARNING – ENTANGLEMENT HAZARD

Do not operate this tool while wearing loose-fitting clothing.
Retain long hair.
Keep hands away from roller bearings and axle pipe while reels are loaded. Could pinch or crush a hand or body part.
FAILURE TO OBSERVE THESE WARNINGS CAN RESULT IN SEVERE INJURY OR DEATH.



WARNING – TOOL USE HAZARDS

Use this tool for manufacturer's intended purpose only. Use other than that which is described in this manual can result in injury or property damage.
Inspect all aspects of the wire pull to ensure safety.
Only qualified personnel should use pulling equipment.
Do not exceed the rated capacity of this tool.
FAILURE TO OBSERVE THESE WARNINGS CAN RESULT IN SEVERE INJURY OR DEATH.

DESCRIPTION AND SPECIFICATIONS

iTOOLCO Axles are designed to safely and quickly support wire reels in conjunction with reel jacks such as iTOOLCO's Real Jacks. All iTOOLCO Axles are manufactured from steel 1026 ASTM A 513.



Axle capacity calculated to a factor of safety three times.

Axle Model No.	Capacity	Size	Weight	Max Reel Width
AXS01	2000 lb (1333 kg)	2.75" x 72 (69.85 x 1829 mm)	36 lb (16.33 kg)	57" (1448 mm)
AX02	6000 lb (2721 kg)	2.75" x 72 (69.85 x 1829 mm)	53 lb (20.4 kg)	57" (1448 mm)
AX03	6000 lb (2721 kg)	2.75" x 60 (69.85 x 1524 mm)	45 lb (20.4 kg)	45" (1143 mm)
AX04	10,000 lb (2721 kg)	3" x 84" (76.2 x 2133 mm)	127 lb (20.4 kg)	72" (1829 mm)

Moment of point load not to exceed 18 inches from either end at max load rating.

*THE AX04 IS NOT POWDER COATED

SET UP AND OPERATION

One set of iTOOLco Real Jacks (or two alike reel stands) and one iTOOLco Axle are required for complete set up.

Set Up and Operation

1. Always wear gloves and eye protection when working with iTOOLco Real Jacks and Axles.
2. Make sure wire reel is chocked to prevent movement during setup.
3. Position the iTOOLco Axle through the center holes of wire reel. (Fig. 1)
4. Place Real Jacks on either side of reel with longer side (T-shaped end) toward the pull.
5. Pull out the pop pin and stand the jack upright.
6. Place hitch pin into vertical hole position.
7. Adjust roller cage to appropriate height and lock into place using the t-handle pop pin.
8. Slide jack into or over axle, leaving 10" between jack and reel to allow for handle to turn.
9. Turn handle to lift reel off floor approximately 1".
10. Level reel by jacking up each side to the appropriate height. Begin pulling wire.
11. When finished dispensing wire, the reel should be lowered in the reverse manner.



Fig. 1



Fig. 2



LIMITED WARRANTY: ITOOLCO AXLES

iTOOLCo warrants all new A covered by his agreement, when properly used, to be free from defects in material and workmanship under normal use and service for which it is intended for a period of one year from date of delivery by the dealer. Date of delivery shall be the date product is placed in possession of the user. NORMAL WEAR FROM USE IS NOT PART OF THIS WARRANTY. This limited warranty is extended to the original user only and is not transferrable to, nor enforceable by any other person.

iTOOLCo will replace free of charge any part(s) of the product found to be defective when such part(s) is returned to iTOOLCo at the address shown below, freight prepaid. If the part(s) is found to be defective, iTOOLCo will refund freight charges paid by you in returning the defective part(s) and prepay replacement part(s) freight charges. iTOOLCo will not be responsible for more than replacement of any defective part(s) and standard freight charges (parcel post or UPS ground rate) of any part(s) found to be defective.

THIS IS THE EXCLUSIVE REMEDY. ITOOLCO SHALL NOT BE RESPONSIBLE OR LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY DEFECTS COVERED BY THIS WARRANTY OR ANY IMPLIED WARRANTY APPLICABLE TO THE PRODUCT INCLUDING, BUT NOT LIMITED TO, PROPERTY DAMAGE, LOSS OF USE OF PRODUCT, LOSS OF TIME, LOSS OF PROFITS, INCONVENIENCE, COMMERCIAL LOSS, LABOR COSTS, SERVICE TRIPS, AND MILEAGE.

Some states do not allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

Dealer/Distributor Warranty Claim Procedure

1. All warranty claims must be pre-approved by iTOOLCo Warranty Department PRIOR to starting any warranty work. Warranty work performed without prior approval will not be considered.
2. All claims must be handled through dealer/distributor.
3. Written approval must be received from iTOOLCo before return of merchandise. A Return Authorization is to be returned with the merchandise which is sent back.
4. All parts must be returned to iTOOLCo at the address shown below, freight prepaid.
5. The serial number of the product and the date of delivery must accompany the part(s) being returned.
6. If the part(s) is found to have failed because of a defect in material or workmanship, replacement will be made on a no-charge basis, and the part(s) returned, freight prepaid. Standard freight charges (parcel post or UPS ground rate) incurred in returning the part(s) will be refunded.
7. For reasons of expediency, replacement and/or repair part(s) may be shipped as soon as possible and billed to the dealer/distributor. When part(s) is returned, if it is covered under warrant, credit will be issued for the part(s) and freight charges.
8. All parts found to be defective shall be retained by and shall become the property of iTOOLCo. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Corporate Address: iTOOLCo
100 Meco Lane
Oak Ridge, TN 37830

